

PS30

Digital Portion Scale



Compact Size • 30 lb/15 kg Capacity • IP65 Protection



- Food Service Portioning
- Industrial Measurement
- Shipping Applications
- Plant Processing
- General Purpose Weighing



The roomy stainless steel lift-off platform may be easily removed for frequent washing in food and chemical applications.



Operation of the scale is simple with only four convenient buttons: Hold, Tare/Backlight, Units, and On/Off.



The scale's 30-lb capacity allows it to be used in a variety of weighing applications, including seed sampling in agriculture.

- Stainless Steel IP65 Washdown Protection
- Weigh in lb, oz, kg, lb:oz, lb:oz with fractions
- Compact and Easy to Use | Only 4 Buttons
- 9.5-in x 7.3-in (24-cm x 19-cm) Platform
- Backlit Blue LCD with 1-in-high Digits
- NSF Certified for Food Service Portioning
- AC Adapter (included) or 4 AA Batteries (not included)
- Removable Stainless Steel Platform

PS30

Digital Portion Scale

DETECTO's model PS30 stainless steel compact countertop portion scale boasts a hefty 30-lb/15-kg capacity. The scale's IP65 washdown rating signifies that the durable PS30 is protected against dust and low-pressure water. This rating is perfectly suited for a commercial kitchen where heavy wash-down cleaning can be a daily necessity. The PS30 features five large 1-in (26-mm) high digits (plus fractional ounces) and a brilliant backlit blue LCD display that may be toggled on or off. The scale offers five selectable weighing units which may be pre-set to display only those desired by the user. Auto-zero circuitry ensures that zero is established on the power-up routine and is maintained throughout operation.




With an IP65 rating, the PS30 may be washed down for easy clean-up when sanitary conditions are required.



An AC adapter is provided with the scale for fixed portioning applications. By adding optional 4 AA batteries, the PS30 has up to 110 hours of continuous use with the backlight off for all mobile weighing tasks such as farmers markets and roadside stands.

Capacity	0-15 lb x 0.1 oz / 15-30 lb x 0.2 oz (0-6 kg x 2 g / 6-15 kg x 5 g)
Weight Display	1.3 in H x 3.7 in W (34 mm H x 95 mm W) backlit LCD with fractions
Weight Digits	1 in H x 0.4 in W (26 mm H x 11 mm W), 5 digits
Weighing Units	lb, oz, lb:oz, lb:oz with fractions, kg
Power	4 AA Alkaline cell batteries (not included) OR 9-15VDC,100mA wall plug-in UL/CSA listed power supply (included)
Battery Life	110 working hours of continuous use without backlight turned on / 80 hours with backlight turned on
Dimensions	11.22 in W x 10.03 in D x 3.54 in H / 285 mm W x 255 mm D x 90 mm H
Platform Size	9.44 in W x 7.28 in D / 240 mm W x 185 mm D
Zero	Established on power up routine and maintained by auto-zero circuitry
Tare	100% of full scale capacity
Temperature	40° to 95° F (5° to 35° C)
Humidity	15% ~85% RH
Construction	Stainless steel
Keys	ON/OFF, HOLD, UNIT, TARE/BACKLIGHT
Product Weight	7.9 lb / 3.6 kg
Shipping Weight	10.4 lb / 4.7 kg
UPC Code	809161192704
IP Rating	IP65
Certification	NSF

Detecto Scale reserves the right to improve, enhance, or modify features and specifications without prior notice.

 **DETECTO**[®]
 A Division of Cardinal Scale Manufacturing Co.
 203 E. Daugherty, Webb City, MO 64870 USA
 Ph: 417-673-4631 or 1-800-641-2008 Fax: 417-673-5001
 www.Detecto.com

Mobile: m.detecto.com

SOLD BY: